

Lateral Pins

<https://ehle-hd.com/en/product/lateral-pins/>



With the **lateral pins**, inspections of pipe branches in pushing operation are possible. The lateral pin is swivelled into the branch and the camera bends into the pipe through the guide.

They are mounted directly on pan and rotate cameras. The pins are available in 2 versions: standard version for explosive environments or as flex pins in spring steel.

Features

- use on pan & rotate camera CAM026 and CAM050
- enables inspection of complete pipe systems across branches
- easy mounting directly on the camera head
- Flex Lateral pins made of shape memory material - no breakage possible. Not for use in ATEX environments.

Attributes

Image	SKU	Productname	Attributes	LxWxH & Weight
	IP595-0122-00	Lateral Pin - 85 mm	length: 85 mm camera: PTP50II Pan & Rotate use: ATEX-Zone	85 × 25 × 25 mm 0.017
	IP533-0826-02	Lateral Pin - 160 mm	length: 160 mm camera: PTP50II Pan & Rotate PTP70II Pan & Rotate use: ATEX-Zone	160 × 25 × 25 mm 0.020
	IP533-0816-02	Lateral Pin - 295 mm	length: 295 mm camera: PTP70II Pan & Rotate	295 × 25 × 25 mm 0.025
	IP595-0122-01	Flexible Lateral Pin - 100 mm	length: 100 mm camera: PTP50II Pan & Rotate	100 × 25 × 25 mm 0.022
	IP595-0126-00	Flexible Lateral Pin - 160 mm	length: 160 mm camera: PTP50II Pan & Rotate	160 × 25 × 25 mm 0.035